


Three-Step Easy Installation Process



STEP 1

Install Our Residential and Commercial RC Model Sprinkler Heads with Protective Cap Still On



STEP 2

Cap Removal Tool Easily Removes the Sprinkler's Protective Cap

STEP 3

Install Cover Plates Up to 3-1/4" with Our Magnetic Cover Plate Installation Tool



Steps 2 & 3 Can Be Used with a 1" CPVC Pipe

SENJU 
SPRINKLER

Senju Sprinkler
Headquarters
30 Muller, Suite 112,
Irvine CA 92618
949-333-1281

Senju Sprinkler Texas Office
935 S. Kimball Ave, Suite 161,
Southlake TX 76092
817-345-7560

www.senjuspinkler.com | info@senjuspinkler.com

